

OPERATING INSTRUCTIONS



OFF ROAD SEATING MANUFACTURER



LGV90/C1

- 1. Adjustable back extension**
At rear hold lip to raise. Push down to lower.
- 2. Adjustable armrests**
Rotate handwheel to right to higher armrest angle.
Rotate to left to lower armrest angle.
- 3. 3-steps lumbar support**
3 positions. Rotate forwards for positions 1, 2 and 3.
Rotate again to return to first position.
- 4. Adjustable backrest**
Push lever backwards and lean back or forwards for desired angle.
- 5. 2-point ALR seat belt (automatic locking)**
Pull belt out. Pull across body. Insert clasp in slot.
- 6. Slide rail adjustment**
Lift lever to operate whilst pulling body forward on seat or push backwards to move seat horizontal.
- 7. Turntable (optional)**
Lift lever and turn to left or right.
Release to lock.
- 8. Semi-automatic weight adjustment (compressor)**
Push in valve to inflate.
Pull out to deflate.
- 9. Horizontal suspension (lock- & unlockable)**
Flip forward to operate.
Flip rearward to lock.
- 10. Stepless height adjustment (limiter)**
When seated and air is inflated in suspension: rotate knob to extend or limit suspension travel (50 - 135 mm). Turn right for higher height. Turn left for lower height.





YOUR OFF ROAD **SEATING** MANUFACTURER



At UnitedSeats we are dedicated to providing a quality service from the initial quotation to final product delivery. Our commitment to service, knowledge and product availability has made us the preferred source for your seating needs.

WWW.UNITEDSEATS.COM

