

OPERATING INSTRUCTIONS



OFF ROAD SEATING MANUFACTURER



CS85/C1

1. Adjustable back extension

At rear hold lip to raise. Push down to lower.

2. Adjustable armrests

Rotate handwheel to right to higher armrest angle. Rotate to left to lower armrest angle.

3. 3-steps lumbar support

3 positions. Rotate forwards for positions 1, 2 and 3. Rotate again to return to first position.

4. Adjustable backrest

Push lever backwards and lean back or forwards for desired angle.

5. 2-point ALR seat belt (automatic locking)

Pull belt out. Pull across body. Insert clasp in slot.

6. Slide rail adjustment

Pull lever outside to operate whilst moving body forward or backwards to move seat horizontal.

7. 3 stage height adjustment (60 mm)

When seat is bolted down lift seat cushion both sides once to attain mid-height position. Lift seat again to top height position. Lift again to return to low setting.

8. Weight adjustment

Turn right for heavy weight.
Turn left for light weight. Check indicator to see weight in kg.





YOUR OFF ROAD **SEATING** MANUFACTURER



At UnitedSeats we are dedicated to providing a quality service from the initial quotation to final product delivery. Our commitment to service, knowledge and product availability has made us the preferred source for your seating needs.

WWW.UNITEDSEATS.COM

